


**READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLING THIS FIXTURE.
CAUTION: POWER MUST BE DISCONNECTED BEFORE ACCESSING THE FIXTURE.**




- 1 SLIDE THE LAMP FIXTURE INTO THE POLE.
- 2 TIGHTEN THE 6x 5/16-18 POLE SETSCREWS @ 75 lbs.in.
- 3 CONNECT THE POWER LINE TO THE SUPPLIED CABLE
- 4 SLIDE THE TUBE OVER THE BALLAST/DRIVER TRAY
- 5 MAKE THE 2 CONNECTIONS (3 CONNECTIONS WITH TAIL LIGHT ONLY)
- 6 MAKE SURE THAT THE SETSCREWS 7 ARE LOOSEN SO THAT THEY CLEAR THE BALLAST/DRIVER TRAY PENETRATION. INSTALL THE BALLAST/DRIVER TRAY TO THE FIXTURE.
- 7 BY TIGHTENING THE 3x SETSCREWS, A DOWNWARD PRESSURE IS APPLIED THRU THE BALLAST/DRIVER TRAY CORE AND WILL SECURE THE BALLAST TRAY AND THE TUBE IN PLACE.
- 8 REMOVE THESE SCREWS TO ACCESS THE OPTICS OR TO CHANGE THE LAMP.
- 9 MAKE SURE THAT THE GROUND IS CONNECTED TO THE GROUND LUG AT THE BASE OF THE POLE.

DESIGNER:	DATE: 2-SEPT-2008	TITRE/TITLE: LDENIS	
VERIF./INSPEC:	DATE:	FEUILLE/ SHEET:	NO. DESSIN/ DRAWING #: 5013194101
			REV.: 1




WIRING DIAGRAM LEN4 LEN5 LUMINAIRES


HIGH INTENSITY DISCHARGE



LED



FLUORESCENT



DESIGNER:	DATE: 2-SEPT-2008	TITRE/TITLE: LDENIS	
VERIF./INSPEC.:	DATE:	FEUILLE/ SHEET:	NO DESSIN/ DRWG #: 5013194101
			REV.: 1